

Operation Manual

Introduction / Precaution / Basic Operation

Vertical Machining Center (Heidenhain NC Controller)

INTRODUCTION

Thank you for choosing the DOOSAN Infracore machine tool. We are proud to have you among our DOOSAN Infracore family of users.

Manuals contain concise information on the installation, setup, operation and maintenance of your machine tool. To make the most of its outstanding performance over a long period, the machine must be properly installed and operating and maintenance procedures must be clearly understood and carefully followed.

We provide the following manuals.

Item	Description	Coverage
	Machine instruction manual	Specification, Maintenance data
	Machine operation manual	Basic operation
Machine manual	Parts list	Machine parts designation
	Electric diagram	Hardware diagram
	Ladder diagram	Software diagram
CNC manual	Instruction manual	NC operation and programming
ONO manuai	Maintenance manual	NC maintenance
Appended data	Extra documents	F.C.F., Parameter sheet, Chuck & Cylinder manual

This manual was considered complete and accurate at the time of publication, however, due to our desire to constantly improve the quality and specification of all our products, it is subject to change or modification.

If you have any questions, please contact the nearest DOOSAN Infracore Technical/Service center.

http://www.doosaninfracore.com

Address: A/S dept., Machine tool & FA BG

DOOSAN Infracore Co., Ltd.

601-3, Namsan-Dong, Seongsan-Gu, Changwon,

Gyeongsangnam-Do, Korea 641-090

Tel.: 82-1600-4522

Fax.: 82-55-281-6181

CONSTRUCTION

SECTION A PRECAUTION

SECTION B GENERAL

SECTION C DESCRIPTIONS

SECTION D OPERATIONS

SECTION A

PRECAUTION

CONTENTS

1.	General	A-1
2.	Machine installation	A-2
3.	Power supply	A-2
4.	Warming up	A-3
5.	Set-up	A-3
6.	Automatic operation	A- 5
7.	Stop operation	A-6
8.	End of work and power off	A-6
9.	Inspection/adjustment/maintenance	A-7

This machine is equipped with safety devices which serve to protect personnel and machine itself from hazards arising from unforeseen accidents. However, operators must not rely exclusively on these safety devices: they must also become fully familiar with the safety guidelines presented below to ensure accident-free operation.

This instruction manual and the nameplates attached to the machine cover show only those hazards which DOOSAN Infracore can predicts. Be aware that they do not cover all possible hazards.

The following warning indications in our manuals are used to draw attention to information of particular importance.

▲ DANGER

1) Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

▲ WARNING

2) Indicates potentially hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION

3) Indicates potentially hazardous situation which, if not avoided, may result in minor or moderate injury or damages to the machine.

NOTICE

4) Indicates comments and items for which care should be exercised.

General

▲ WARNING

1) Fully understand the machine specification and function, and perform the work in specified ways.

NOTICE

2) Prepare work process and range before performing work.

▲ WARNING

3) Indicate clearly the trained staff for each work, and perform the work by indicated one.

NOTICE

4) In more than one staff is necessary absolutely, all involved persons must cooperate and be able to communicate.

▲ WARNING

5) Always be sure to wear suitable clothes.

⚠ CAUTION

6) Always check that there are no obstacles in and around the machine.

▲ WARNING

7) Do not handle the electrical equipment with wet hand.

⚠ CAUTION

8) Inspect, adjust and maintain periodically refering to check points described in this manual.

⚠ CAUTION

9) Check the setting value of the machine, and never change that without intention.

▲ WARNING

10) Never disassemble and adjust the devices and covers for safety without intention

A WARNING

11) Working inside of machine is especially dangerous. In this case, always turn off the main power.

2. Machine installation

NOTICE

1) Fully understand the process in Machine instruction manual.

NOTICE

2) Prepare work process, and perform pre-inspection.

NOTICE

3) In cooperation, all involved persons must be able to communicate...

NOTICE

4) Check that all of necessary implements and tools are prepared.

⚠ CAUTION

5) Use standard devices and tools.

3. Power supply

NOTICE

1) Fully understand the process in Machine operation manual.

⚠ CAUTION

2) Always check that there are no obstacles against operation in and around the machine.

NOTICE

3) Check the electric cabinet doors are closed.

⚠ CAUTION

4) A momentary power stoppage due to a power failure or lightening can cause an accident. Therefore, turn off the main power if abnormal fluctuation of power is anticipated.

⚠ CAUTION

5) If the machine stops due to a power failure, turn off the main power immediately.

4. Warming up

NOTICE

1) Prepare the extra program for warming up.

⚠ CAUTION

2) Perform the warming up before daily operation of machine.

⚠ CAUTION

3) Perform checking and inspection of each device's function during warming up.

5. Set-up

NOTICE

1) Fully understand the process in operation manual.

⚠ CAUTION

2) Check the setting value of all gages and state of moving parts.

A WARNING

3) On handling heavy weight, use a crane, hoist or make a teamwork.

⚠ CAUTION

4) The work light will be very hot after it has been lit for a long period. Be careful not to touch it.

⚠ CAUTION

5) Be careful not to operate the wrong switch.
Visually check the switches on the operation panel before operating them.

A WARNING

6) When load and unload workpiece, be careful that the machine stops completely.

A WARNING

7) Never touch any moving unit while the machine is operating. Be careful that the machine stops completely before touching it.

⚠ CAUTION

8) When loosening the bolts on the fixture, be sure to loosen them gradually.

⚠ CAUTION

9) Clean thoroughly the chips and foreign matters on workpiece and tools before loading.

⚠ CAUTION

10) Clamp the workpiece and cutting tools securely.

⚠ CAUTION

11) Depth of cut and cutting feed must be selected with small values.

⚠ CAUTION

12) Never put any tools or instruments on the machine operation panel or on any machine part.

⚠ CAUTION

13) Check that set-up is finished completely.

⚠ CAUTION

14) If set-up is changed, check the process with single block operation to find out any other trouble.

⚠ CAUTION

15) On working in new set-up state, be sure to check the set-up state once again before the machine operation.

6. Automatic operation

NOTICE

1) Fully understand the process in Machine operation manual.

▲ WARNING

2) Do not lean on the machine while the machine is operating.

⚠ CAUTION

Be careful not to operate the wrong switch.
 Visually check the switches on the operation panel before operating them.

▲ WARNING

4) Always close all doors before automatic operation.

⚠ CAUTION

5) Before performing spindle rotation, tool change and axis feed, etc., be careful those operations are safe.

⚠ CAUTION

6) Check that all switches and moving parts are in correct position before automatic operation.

ACAUTION

7) When running a new program for the first time, check the program thoroughly beforehand.

NOTICE

After debugging any bug in program, start the program in single block mode. If no error occurs, start it in automatic mode.

▲ WARNING

8) Never touch any moving unit while the machine is operating. Be careful that the machine stops completely before touching it.

▲ WARNING

9) Never open doors and covers in automatic operation.

⚠ CAUTION

10) On automatic operation, be careful not to touch any other switches.

7. Stop operation

▲ WARNING

1) Stop machine immediately with pushing Emergency stop switch when any trouble occurs.

⚠ CAUTION

- 2) Fully understand each machine state according to each stop operation.
- 3) Check that the machine stops completely.

8. End of work and power off

▲ WARNING

1) Check that the machine stops completely.

⚠ CAUTION

2) Clean the machine inside.

NOTICE

3) Stop the machine to the specified position.

⚠ CAUTION

4) Turn off the main power.

NOTICE

5) Check all switches off.

Inspection/adjustment/maintenance

NOTICE

1) Fully understand the process in Machine instruction manual.

NOTICE

2) Clarify the trouble state referring to its operator's advice.

NOTICE

3) Prepare work process and range before performing work.

⚠ CAUTION

4) Indicate clearly the trained staff for each work, and perform the work by indicated one.

NOTICE

5) Share informations with each staff.

NOTICE

6) If teamwork is necessary, discuss enough plan for maintenance with other part and the cooperator.

▲ WARNING

7) Notify "On maintenance" around the machine while maintenance is performed.

▲ WARNING

8) Turn off the main power in case that any danger can occur when power on, and attach the warning sign saying "Never power on" around main switch.

▲ WARNING

9) Always turn off the main power before beginning any work inside of the machine, and attach the warning sign saying "Never power on" around main switch.

If a operator has to be stay inside of machine area for anywork, keep the main door on opening status with locking pin avoid operator trapping.

A DANGER

10) Never touch or operate electrical cables, devices, switches with wet hand.

A WARNING

11) Use a ladder or any safety device to reach high.

⚠ CAUTION

12) Use standard and specified tools.

ACAUTION

13) Do not put the tools or clothes on the moving parts.

▲ WARNING

14) On handling heavy weight, use a crane, hoist or make a teamwork.

▲ WARNING

15) When using a crane, use only specified wires, shackles and gigs.

⚠ CAUTION

16) Be sure to use specified parts on changing parts.

SECTION B

GENERAL

CONTENTS

1.	NC Variation	B-1
2.	OP. Panel Variation	B-2
3	Operation symbol	B-3

In this section, the kind of operation device according to machine specification and the basic function of them are explained simply.

As the contents in this section are common to all machine tools, it should be observed carefully.

NOTICE

Figure and description in this manual explain general articles in machine operation.

So there are some difference in explanation depend on each model.


Machine name comparison table

<Contents>

Item	Description Remark		Page
1	NC variation	- Shape according to NC specification	B-1
2	OP. Panel variation - English, For CE		B-2
3	Operation symbol	- Explanation of symbol according to ISO standard	B-3

1. NC Variation

iTNC530 (HEIDENHAIN)



2. OP. Panel Variation

MB420



MB520



3. Operation symbol

1) Symbol for device description

Туре	Number	Symbol	Description
	1	O	Split screen layout
Keys on	2	0	Toggle display between machining and programming modes
visual display unit	3		Soft keys for selecting functions on screen
	4		Shift between soft-key rows
alphanumeric keyboard	5	QWERTY	File names, comments
	6	GFSTM	DIN/ISO programming
	7	4	Manual Operation
	8	(A)	Electronic Hand wheel
Machine	9		smarT.NC
operating modes	10		Positioning with Manual Data Input
	11		Program Run, Single Block
	12	1	Program Run, Full Sequence
Programming	13	�	Programming and Editing
modes	14		Test Run
	15	PGM MGT	Select or delete programs and files, external data transfer
	16	PGM CALL	Define program call, select datum and point tables
Program/ file management	17	MOD	Select MOD functions
, TNC functions	18	HELP	Display help text for NC error messages, call TNC guide
	19	ERR	Display all current error messages
	20	CALC	Show pocket calculator

Туре	Number	Symbol	Description
Navigation	21		Move highlight
keys	22	GOTO П	Go directly to blocks, cycles and parameter functions
	23	APPR DEP	Approach/depart contour
	24	FK	FK free contour programming
	25	L/P	Straight line
Due sue sereire e	26	o cc	Circle center/pole for polar coordinates
Programming path movements	27	∞ °	Circle with center
	28	CR	Circle with radius
	29	CT	Circular arc with tangential connection
	30	CHF	Chamfering
	31	RND	Corner rounding
Tool	32	TOOL DEF	Define tool data in the program
functions	33	TOOL CALL	Call tool data
	34	CYCL CYCL CALL	Define and call cycles
Cycles, subprograms and program	35	LBL CALL	Enter and call labels for sub programming and program section repeats
section repeats	36	STOP	Program stop in a program
	37	TOUCH PROBE	Define touch probe cycles
Coordinate axes and	38	X Y	Select coordinate axes or enter them into the program
numbers: Entering and editing	39	0 9	Numbers
	40	•	Decimal point
	41	7+	Reverse algebraic sign
	42	Р	Polar coordinate input

Туре	Number	Symbol	Description
	43	I	Incremental values
	44	Q	Q parameter programming/Q parameter status
	45	+	Save actual position or values from calculator
	46	NO ENT	Skip dialog questions, delete words
	47	ENT	Confirm entry and resume dialog
	48	END	Conclude block and exit entry
	49	CE	Clear numerical entry or TNC error message
	50	DEL 🗆	Abort dialog, delete program section
	51	SPEC FCT	Show special functions
Special functions /	52		smarT.NC: Select next tab on form
smarT.NC	53		smarT.NC: Select first input field in previous/next frame
About feed speed/spindl	54		Roh feed speed control [pu]
e speed Roh control [pu]	55	- (C) (C)	Roh spindle speed control [pu]

2) Machine operating panel

Number	Symbol	Description
1		Unlock door
2	t	Coolant
3		Coolant(internal)
4	*	Coolant(external)
5	14	Rinse water jet
6		Spot light
7	၁၀င	Chip removal
8	200	Chip conveyor
9		Tool change
10	(30%)	Tool changer left
11	(* * * * * * * * * * * * * * * * * * *	Tool changer right
12		Unlock tool
13		Lock tool
14	\vdash	Retract aixs
15		No symbol
16	NC	NC start
17	NC O	NC stop
18	W W	Feed rate
19	Image: Control of the	Rapid traverse
20	2 D	Permissive key
21	X-X+	

3) Machine operating panel

Number	Symbol	Description
1	ACTL	Actual or nominal coordinates of the current position
2	XYZ	Machine axes; the TNC displays auxiliary axes in lower-case letters. The sequence and quantity of displayed axes is determined by the machine tool builder. Refer to your machine manual for more information.
3	ESM	The displayed feed rate in inches corresponds to one tenth of the effective value. Spindle speed S, feed rate F and active M functions.
4	*	Program run started.
5	→	Axis is locked
6	\otimes	Axis can be moved with the handwheel
7		Axes are moving under a basic rotation
8		Axes are moving in a tilted working plane
9	W	The M128 function or TCPM FUNCTION is active
10		The Dynamic Collision Monitoring function (DCM) is active
11	* I	The Adaptive Feed Function (AFC) is active (software option)
12	8	One or more global program settings are active (software option
13	(Number of the active presets from the preset table. If the datum was set manually, the TNC displays the text MAN behind the symbol.

SECTION C

DESCRIPTIONS

CONTENTS


1.		Electric cabinet	
2.		Main OP. devices	
	2.1	Visual display unit	
	2.2	PLC Soft keys	
	2.3	Handwheel (HR410)	
3.		ATC OP. devices	
	3.1	CAM ATC OP. devices*)	

In this chapter, the name and function of each operational device are explained briefly, and the figure below shows the basic arrangement of them for the reference.

NOTICE

Figure and description in this manual explain general articles in machine operation.

So there are some difference in explanation depend on each model.



Item	Description	Remark	Page
1	Electric cabinet		C-1
2	Main OP. Devices		C-2
3	ATC OP. Devices	- Kind/name/function of	C-17
4	APC OP. Devices	attached operational device	
5	Tool Unclamp OP. Panel		
6	Chip Conveyor OP. Devices		

1. Electric cabinet

As built with a viriety of electric device, it has also the function to tum on/off the main power.



Symbol	Description	Remark	Page
1	Main Power N.F.B. Switch	- To turn on/off the main power - Automatic cutting off over voltage	

2. Main OP. devices

As the device for operation the machine and programming, it consists of monitor and operational devices, etc..

Symbol	Description	Remark	Page
1	MDI/CRT Devices	- Refer to B.2.1	
2	Main OP. Panel	- Refer to B.2.2	
3	MPG, Manual Pulse Generator	- Refer to B.2.3	
4	AUX. OP. Panel	- Refer to B.2.4 (Except for some models)	
5	Power Outlet	- Power connection with external Device 220V	
6	Input/Output Device	- Interface with external device	

2.1 Visual display unit

NOTICE

Please refer to NC operation manual for detail descriptions.



Symbol	Description	Remark
1	Header	When the TNC is on, the selected operating modes are shown in the screen header: the machining mode at the left and the programming mode at right.
2	Soft keys	In the footer the TNC indicates additional functions in a soft-key row.
3	Soft-key keys	Soft-key selection keys
4	soft-key rows key	Shift between soft-key rows
5	screen layout key	Sets the screen layout
6	Shift key for mode	Shift key for switchover between machining and programming modes
7	Soft-key for PLC	Soft-key selection keys for machine tool builders
8	Switches soft-key row for PLC	Switches soft-key rows for machine tool builders

2.1.1 Sets the screen layout

You select the screen layout yourself: In the PROGRAMMING AND EDITING mode of operation, for example, you can have the TNC show program blocks in the left window while the right window displays programming graphics. You could also display the program structure in the right window instead, or display only program blocks in one large window. The available screen windows depend on the selected operating mode.

To change the screen layout:



Press the SPLIT SCREEN key: The soft-key row shows the available layout options

Symbol	Operating Mode	Soft key	Window	
1		POSITION	Positions	
2		POSITION + STATUS	Left: positions, right: status display	
3		POSITION + KINEMATICS	Left: positions, right: active collision objects(FCL4 function).	
4	Manual operation and electronic handwheel	### ### ### ##########################		
	Positioning with manual data input	PROGRAM + STATUS PROGRAM + KINEMATICS	Program Left: program blocks, right: status display Left: program blocks, right: active collision objects (FCL4 function). If this view is selected, then the TNC indicates a collision with a red frame around the graphics window.	
8		Positioning wit ### ### ### #### #### ##############	h manl.data input	
9	Programming and editing	PGM	Program	
10		PROGRAM + SECTS	Left: program blocks, right: program structure	


Symbol	Operating Mode	Soft key	Window
11		PROGRAM + GRAPHICS	Left: program blocks, right: graphics
		PROGRAM + 3D LINES	Left: program blocks, right: 3-D line graphics
		Hercal Progra	mming and editing
		DEEDY PAR DOMENT PH B.K. FORM 0.1 Z X-00 Y-00 1 D.K. FORM 0.2 X-00 Y-00 1 P.K. X-0 Y-00 RD PRIX 2 P.FOLL K-00 Y-00 PRIX 3 P.FOLM 0.2 X-00 PRIX 5 P.FOLM 0.2 X-00 PRIX 1 P.K. X-0 Y-00 PRIX 1 P.FOLM 0.2 X-00 PRIX 1 P.FOLM 0.2 X-00 PRIX 2 P.FOLM 0.2 X-00 PRIX 3 P.FOLM 0.2 X-00 PRIX 4 P.FOLM 0.2 X-00 PRIX 5 P.FOLM 0.2 X-00 PRI	COV+8 COV+8 DIGMANNSS COV+8 DIGMANNSS COV+8 DEFERT SESSE
		T 1	FINO START START START
	Test run	Harmus Test Test Harmus	2 2-52 12-53 SET SING SING SING SING SING SING SING SING
	Program run, full sequence and program	PGM	Program
	run, single block	PROGRAM + SECTS	Left: program, right: program structure
		PROGRAM + STATUS	Left: program, right: status
		PROGRAM + GRAPHICS	Left: program, right: graphics
		GRAPHICS	Graphics
		PROGRAM + KINEMATICS	Left: program blocks, right: active collision objects (FCL4 function). If
		+ KINEMATICS	collision objects (FCL4 function). If this view is selected, then the TNC


Symbol	Operating Mode	Soft key	Window
			indicates a collision with a red frame around the graphics window.
		KINEMATICS	Active collision objects (FCL4 function) If this view is selected, then the TNC indicates a collision with a red frame around the graphics window.
		Program run, fu	and edition
			51:5
		+26.342 Y +B +0.000+C	-51.462 Z +250.800
		Eggston State Ta	S1 0.000
		T T T	POSE BLOCK TOR. DRIVE TROLE TEST THREE TRULE
		Program run, ful	and equiting
		0 00237 90* 17611 PM 1 DLL FORM 0.1 Z x-60 V-70 2 BLL FORM 0.2 X-100 V-70 Z 2 BLL FORM 0.2 X-100 V-70 Z 2 T-70 L O.L. 3 Z 02000 DD F1000 1 L X-20 V-60 Z-16 BB 0 800 520 7 L X-70 V-50 Z-16 0 CT X-70 V-50 1 T-70	2-200 red red
		48 5-15F	97 : 3 18 (33)
		+25.342 Y +B +0.000+C	-51.462 Z +259.000 +0.000 S1 0.000
		acts Stor 7.5	PIGE SLOX 103L SCITUT 106L TABLE 1638 THELE T S L


2.1.2 Path contours - Cartesian Coordinates


Function	Key	Tool movement	Required input
Line L		Straight line	Coordinates of the end points of the straight line
Chamfer CHF	CHF	Chamfer between two straight lines	Chamfer side length
Circle center CC	\rightarrow	None	Coordinates of the circle center or pole
Circle C	C C	Circular arc around a circle center CC to an arc end point	Coordinates of the arc end point, direction of rotation
Circular arc CR	CR	Circular arc with a certain radius	Coordinates of the arc end point, arc radius, direction of rotation
Circular arc CT	CT p	Circular arc with tangential connection to the preceding and subsequent contour elements	Coordinates of the arc end point
Corner rounding RND	RND	Circular arc with tangential connection to the preceding and subsequent contour elements	Rounding radius R
FK free contour programming	FK	Straight line or circular path with any connection to the preceding contour element	Path Contours - FK free contour programming

2.2 PLC Soft keys









Soft key	Function
	DIAG AXES/SPINDLE 12 2-7 352 4-3 5-8 8-8 7-6 Motor Temperature [Degree] 23 25 27 26 23 254 254 Motor Utilization [%] 2
DIAGNOSIS S,814	Display the second part of the drive diagnosis DIAG AXES/SPINDLE Second part of the drive diagnosis Hotor Temperature [Degree] 254 Hotor Utilization [X] 8 8 10 11 12 13 14 B 8 10 11 12 13 14 IZT Limitation: - 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
DIAGNOSIS Step	Display the third part of the drive diagnosis DIAG AXES/SPINDLE 1 2 3 4 5 5 7 Rxis X V 2 8 8 8 C Step 5 5 5 1 1 1 1 Step 6 6 6 6 6 6 6 Legend 0 = Initialization 1 = Wait in position 2 = Current/speed control on 3 = Close positioning loop 4 = Unclasping 5 = Positioning 6 = Clamping 7 = Open positioning loop 8 = Current/speed control off 9 = Step end
DIAGNOSIS T	Display tool change diagnosis

Soft key	Function
	DIAG TOOL CHANGE (-1) : * TC auto - Double arm * CREE(0): 00 TC auto Start (+1) : 00 TC auto Start Standy Pocket : 5 TOOL Pocket W282 : 0 TOOL Number W284 : 0 I Strobe M4073: 0 T2 M4520: 0 T0 M4521: 1 T W Pocket M4522: 0 T W/O Pocket M4523: 0 X Y Z 4 5 E 7 8 9 PLC-Positioning : 0 0 0 0 0 0 0
DIAGNOSIS T-MAG	DIRG TC MAGAZINE (-1): * TC magazine - PLC axis * (MHE(0): * 00 Magazine start (+1): 01 Tool def quit TC magazine active: off T CALL strobe M4073: 0 T DEF strobe M4074: 0 TOOL pumber U264: 0 TOOL number U264: 0 Standby pocket : 5 Nominal position: seesee
X,Y,Z ?	Display tool magazine diagnosis STATUS AXES Axes released : 0007 in position : ffffffff in notion : 0000 not pass over ref : 0000 End position + : 0000 End position - : 0000 activate open loop : 0078 open loop : 0078 open loop : 0078 no axes monitoring: 0000 Acti/noml transfer: 0000 Ref end position : 0000 Feed released : 007f Hanual motion + : 0000 Manual motion - : 0000
STATUS 7	Display spindle status

Soft key	Function
	STATUS SPINDLE Drive release : 0 Drive ready : 0 Orientation : 0 Loop open : 1 in position : 0 no reference : 0 not in rasp : 1 Rotation left : 0 Soeed MPSS20 : 0 Thread CVCL 2 : 0 Thread CVCL 17 : 0 nominal rpm : 0 actual rpm : 0 End speed : 0 Programmed rpm : 100
PLC POSIT	Display status of PLC positioning PLCPOS PLC -> NC The active feedbate Status 1 X +0.000 0 0 0 3 Z +0.000 0 0 0 4 - +0.000 0 0 0 5 B +0.000 0 0 0 7 C +0.000 0 0 0 8 - +0.000 0 0 0 9 - +0.000 0 0 0 10 - +0.000 0 0 0 11 - +0.000 0 0 0 11 - +0.000 0 0 0 11 - +0.000 0 0 0 11 - +0.000 0 0 0 11 - +0.000 0 0 0 11 - +0.000 0 0 0 11 - +0.000 0 0 0 11 - +0.000 0 0 0 11 - +0.000 0 0 0 11 - +0.000 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 11 - +0.000 0 0 0 0 0 11 - +0.000 0 0 0 0 0 11 - +0.000 0 0 0 0 0 11 - +0.000 0 0 0 0 0 11 - +0.000 0 0 0 0 0 11 - +0.000 0 0 0 0 0 11 - +0.000 0 0 0 0 0 11 - +0.000 0 0 0 0 0 11 - +0.000 0 0 0 0 0 11 - +0.000 0 0 0 0 0 11 - +0.000 0 0 0 0 0 11 - +0.000 0 0 0 0 0 0 11 - +0.000 0 0 0 0 0 0 11 - +0.000 0 0 0 0 0 0 0 11 - +0.000 0 0 0 0 0 0 0 0 11 - +0.000 0 0 0 0 0 0 0 0 0 0 11 - +0.000 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0
² x↑ Ž	11 - +0.000 0 0 0 12 - +0.000 0 0 0 13 - +0.000 0 0 0 14 - +0.000 0 0 0 Status 0: No PLC positioning was started 1: Target position reached 2: PLC positioning was started 3: Target position not reached 4: Target position outside limit 5: Posit impossible (free rotation) 6: Posit temp stopped (NC stop)
DOC M M03 M04	Display documentation of the M-functions M Function Metaline programed stop Metaline programed stop Metaline program Mitaline program
DOC I/O IZ4 013	Display documentation of the inputs and outputs

Soft key	Function
	PLC Output/Input

2.3 Handwheel (HR410)





Select the Electronic Handwheel operating mode.




Press and hold a permissive button.


Symbol	Description	Function
1	EMERGENCY STOP button	
2	Handwheel	
3	Axis address keys	
4	Actual-position-capture key	
5	Actual-position-capture key	
6	Keys for defining the feed rate (slow, medium, fast; the feed rates are set by the machine tool builder)	
7	Direction in which the TNC moves the selected axis	
8	Machine function (set by the machine tool builder)	

3. ATC OP. devices

3.1 CAM ATC OP. devices*)







<English>

<For CE>

Symbol	Description	Function
1	Emergency stop switch	- Refer to 2.2.2.4
2	Manual/Auto. Selection Toggle switch	 To select ATC OP. devices' manual operation mode possible/ impossible
3	TOOL/MAG. CW Rotation Button	- To turn the tool magazine in CW
4	TOOL/MAG. CCW Rotation Button	- To turn the tool magazine in CCW
5	Tool Pull-Outer	- To unload the tool into magazine

^{*)} Applied machines

SECTION D

OPERATION

CONTENTS

1.		Power ON	D-1
2.		Power OFF	D-3
3.		Ethernet Interface	D-4
	3.1	Settings on the iTNC	D-4
	3.2	Settings on a PC with Windows XP	D-5
	3.3	Data transfer between the TNC and TNCremoNT	D-6
4.		Position Display Types	D-7
	5.1	To traverse with the machine axis direction buttons	D-8
	5.2	Incremental jog positioning	D-8
6.		Spindle speed S, Feed Rate F and Miscellaneous Functio	ns MD-9
7.		Datum setting	
7.	7.1	Datum setting Datum Setting Datum setting with axis keys	D-10
7.	7.1 7.2	· ·	D-10 D-10
7.		Datum Setting Datum setting with axis keys	D-10 D-10 D-11
7.	7.2	Datum Setting Datum setting with axis keys Datum management with the preset table	D-10 D-10 D-11
	7.2 7.3	Datum Setting Datum setting with axis keys Datum management with the preset table Manually saving the datums in the preset table	D-10 D-10 D-11 D-12 ode . D-14
7. 8.	7.2 7.3	Datum Setting Datum setting with axis keys Datum management with the preset table Manually saving the datums in the preset table Activating a datum from the preset table in the Manual Operation me	D-10D-10D-11D-12 ode . D-14
	7.2 7.3 7.4	Datum Setting Datum setting with axis keys Datum management with the preset table Manually saving the datums in the preset table Activating a datum from the preset table in the Manual Operation mo	D-10D-10D-11D-12 ode . D-14D-15
	7.2 7.3 7.4 8.1	Datum Setting Datum setting with axis keys Datum management with the preset table	D-10D-10D-11D-12 ode . D-14D-15D-15
	7.2 7.3 7.4 8.1 8.2	Datum Setting Datum setting with axis keys	D-10D-10D-11D-12 ode . D-14D-15D-15D-17D-18

9.	ATC Operation	D-22
9.1	Manual ATC Operation	D-22
10.	Manual Data Input (MDI)	D-23
11.	Program Run	D-24
11.1	Program start	D-24
11.2	Mid-program startup (block scan)	D-25
11.3	Automatic Program Start	D-26
11.4	Optional Block Skip	D-26
11.5	Optional Program-Run Interruption	D-26
12.	File Management	D-27
12.1	Fundamentals	D-27
12.2	Calling the file manager	D-28
12.3	Functions of the file manager	D-29
12.4	Selecting drives, directories and files	D-30
12.5	Creating a new part program	D-31
12.6	Programming tool movements in conversational format	D-32

In this chapter, the method are explained with the process and the devices, which are necessary for each step from power ON to power OFF after end of work.

The contents below is showing overall process and main work.

⚠ CAUTION

1. Before operation, fully understand the machine specifications in machine instruction manual.

⚠ CAUTION

2. Programmer must understand fully the contents in NC instruction manual.

1. Power ON

As the process preparing to operate the machine, there can be some differences in the actual action by operating devices.

1) Main power on



Step	Operation	Location	Remark
1	Check the machine state and interference	Machine	- Refer to precautions/ instruction manual
2	Main N.F.B. switch ON	Electric cabinet	- Spindle fan ON - Work light available

2) NC power on

Step	Display	Operation
	POWER INTERRUPTED	Switch on the power supply for control and machine. The TNC starts the operating system. This process may take several minutes. Then the TNC will display the message "Power interruption."
	1 1	Power interrupted Programming and editing
1		Before the control is shineed to the end user, the feature content level of the NO software sust be set. Load the NO software intended for the control shipsent and then, under MOD, enter the kewsord "SIX". Enter the option number "53" and confire the feature of the kewsord "SIX". Enter the option number "53" and confire the feature of the keysord "SIX". Enter the option number "53" and confire the feature of the keysord the keysord that the feature of the keysord that the set in the feature of the control is SIX number and NO software number. After the displayed number of new start-ups, the control will sutcessically set the value of the currently loaded NC software.
	* 1	OFF (2)
2	COMPILE PLC PROGRAM	Press the CE key: The TNC converts the PLC program Power interrupted Programming and addition Programming and addition
3	RELY EXT. DC VOLTAGE MISSING	Switch on the control voltage: The TNC checks operation of the emergency stop circuit and goes into the reference run mode
4	MANUAL OPERATION TRAVERSE REFERENCE POINTS	Cross the reference points manually in the displayed sequence: For each axis press the machine START button, or Cross the reference points in any sequence: Press and hold the machine axis direction button for each axis until the reference point has been traversed.

2. Power OFF


To prevent data from being lost at switch-off, you need to shut down the operating system of the TNC as follows:

Step	Operation	
1	(m)	Select the Manual Operation mode
2	OFF	Select the function for shutting down, confirm again with the YES soft key
3		TNC displays the message Now you can switch off the TNC in a pop-
٥	up window	, you may cut off the power supply to the TNC
	END	Remember that pressing the END key after the control has been shut
4		down restarts the control. Switch-off during a restart can also result in
		data loss!


3. Ethernet Interface

The TNC is shipped with a standard Ethernet card to connect the control as a client in your network. The TNC transmits data via the Ethernet card with the **smb** protocol (**s**erver **m**essage **b**lock) for Windows operating systems, or the **TCP/IP** protocol family (Transmission Control Protocol/Internet Protocol) and with support from the NFS (Network File System). The TNC also supports the NFS V3 protocol, which permits higher data transfer rates.


3.1 Settings on the iTNC



3.2 Settings on a PC with Windows XP




3.3 Data transfer between the TNC and TNCremoNT



Step	Operation
1	Once you have started TNCremoNT, you will see a list of all files that are stored in the active directory in the upper section of the main window 1. Using the menu items <file> and <change directory="">, you can change the active directory or select another directory on your PC.</change></file>
2	Select <file>, <setup connection="">. TNCremoNT now receives the file and directory structure from the TNC and displays this at the bottom left of the main window 2.</setup></file>
3	To transfer a file from the TNC to the PC, select the file in the TNC window with a mouse click and drag and drop the highlighted file into the PC window 1.
4	To transfer a file from the PC to the TNC, select the file in the PC window with a mouse click and drag and drop the highlighted file into the TNC window 2.

4. Position Display Types




Display	Function
NOML	Nominal position: the value presently commanded by the TNC
ACTL	Actual position; current tool position
REF	Reference position; the actual position relative to the machine datum
DIST	Distance remaining to the programmed position; difference between actual and target positions
LAG	Servo lag; difference between nominal and actual positions (following error)
DEFL	Deflection of the measuring touch probe
M118	Traverses that were carried out with handwheel super positioning (M118) (only Position display 2)

5. Moving the Machine Axes


5.1 To traverse with the machine axis direction buttons

Step	Operation	
1		Select the Manual Operation mode
2	X	Press the machine axis direction button and hold it as long as you wish the axis to move, or
	(X) (I)	Move the axis continuously: Press and hold the machine axis direction button, then press the machine START button.
3	0	To stop the axis, press the machine STOP button.
4	You can move several axes at a time with these two methods. You can change the feed rate at which the axes are traversed with the F soft key	

5.2 Incremental jog positioning



6. Spindle speed S, Feed Rate F and Miscellaneous Functions M



7. Datum setting

You fix a datum by setting the TNC position display to the coordinates of a known position on the workpiece.


Preparation

Clamp and align the workpiece.

Insert the zero tool with known radius into the spindle.

Ensure that the TNC is showing the actual position values.

7.1 Datum Setting Datum setting with axis keys



Programming and editing Table editing Rotation angle? File: PRESET.PR +1.59 22 +422.272 +0.7858 23 +230.349 -204.0295 24 +0 25 +0 +0 28 +12 0% S-IST 0% SENm] 09:45 X -4.598 Y -321.722 Z +100.250 +0.000 +A +0.000 +B +0.000 +a +0 +0.000 Info 1/3 三 S 1 0.000 CORRECT ENTER EDIT SAVE NEW PRESET THE CURRENT -PRESET

7.2 Datum management with the preset table

Saving the datums in the preset table

The preset table has the name PRESET.PR, and is saved in the directory

TNC:\. PRESET.PR is editable only in the Manual Operation and Electronic Handwheel modes. In the Programming and Editing mode you can only read the table, not edit it. It is permitted to copy the preset table into another directory (for data backup). Lines that were written by your machine tool builder are also always write-protected in the copied tables. You therefore cannot edit them.

Never change the number of lines in the copied tables! That could cause problems when you want to reactivate the table.

To activate a preset table copied to another directory you have to copy it back to the directory **TNC:**\.

7.3 Manually saving the datums in the preset table

Step	Operation	
1	Select the Manual Operation mode	
2	xyz	Move the tool slowly until it touches (scratches) the workpiece surface, or position the measuring dial correspondingly.
3	PRESET	Displaying the preset table: The TNC opens the preset table and sets the cursor to the active table row.
4	CHANGE PRESET	Select functions for entering the presets: The TNC displays the available possibilities for entry in the softkey row. See the table below for a description of the entry possibilities.
5	+	Select the line in the preset table that you want to change (the line number is the preset number).
6	1	If needed, select the column (axis) in the preset table that you want to change.
7	CORRECT THE PRESET	Use the soft keys to select one of the available entry possibilities (see the following table).

Soft key	Function	
Directly transfer the actual position of the tool (the measuring the new datum: This function only saves the datum in the accurrently highlighted.		
ENTER NEU PRESET	Assign any value to the actual position of the tool (the measuring dial): This function only saves the datum in the axis which is currently highlighted. Enter the desired value in the pop-up window.	
CORRECT THE PRESET	Incrementally shift a datum already stored in the table: This function only saves the datum in the axis which is currently highlighted. Enter the desired corrective value with the correct sign in the pop-up window. If inch display is active: enter the value in inches, and the TNC will internally convert the entered values to mm.	
EDIT CURRENT FIELD	Directly enter the new datum without calculation of the kinematics (axis-specific). Only use this function if your machine has a rotary table, and you want to set the datum to the center of the rotary table by entering 0. This function only saves the datum in the axis which is currently highlighted. Enter the desired value in the pop-up window. If inch display is active: enter the value in inches, and the TNC will internally convert the entered values to mm.	
SAVE PRESET	Write the currently active datum to a selectable line in the table: This function saves the datum in all axes, and then activates the appropriate row in the table automatically. If inch display is active: enter the value in inches, and the TNC will internally convert the entered values to mm.	

Editing the preset table

Soft key	Editing function in table mode
BEGIN	Select beginning of table
END	Select end of table
PAGE	Select previous page in table
PAGE	Select next page in table
CHANGE PRESET	Select the functions for preset entry
ACTIVATE PRESET	Activate the datum of the selected line of the preset table
APPEND N LINES	Add the entered number of lines to the end of the table (2nd soft-key row)
COPY FIELD	Copy the highlighted field (2nd soft-key row)
PASTE FIELD	Insert the copied field (2nd soft-key row)
RESET LINE	Reset the selected line: The TNC enters – in all columns (2nd soft-key row)
INSERT	Insert a single line at the end of the table (2nd soft-key row)
DELETE	Delete a single line at the end of the table (2nd soft-key row)

7.4 Activating a datum from the preset table in the Manual Operation mode


Step	Operation	
1	Select the Manual Operation mode	
2	Display the preset table.	
3	Select the datum number that you want to activate, or	
3	With the GOTO key, select the datum number that you want to activate. Confirm with the ENT key.	
4	Activate the preset. PRESET	
5	Confirm activation of the datum. The TNC sets the display and if defined the basic rotation.	
6	Leave the preset table.	
	Activating a datum from the preset table in an NC program To activate datums from the preset table during program run, use Cycle 247. In Cycle 247 you define the number of the datum that you want to activate	

8. Tool

8.1 Tool data

Requirements for tool compensation

You usually program the coordinates of path contours as they are dimensioned in the workpiece drawing. To allow the TNC to calculate the tool center path i.e. the tool compensation you must also enter the length and radius of each tool you are using. Tool data can be entered either directly in the part program with **TOOL DEF** or separately in a tool table. In a tool table, you can also enter additional data for the specific tool. The TNC will consider all the data entered for the tool when executing the part program.




Tool numbers and tool names

Each tool is identified by a number between 0 and 32767. If you are working with tool tables, you can also enter a tool name for each tool. Tool names can have up to 16 characters. The tool number 0 is automatically defined as the zero tool with the length L=0 and the radius R=0. In tool tables, tool T0 should also be defined with L=0 and R=0.

Tool length L

You should always enter the tool length L as an absolute value based on the tool reference point. The entire tool length is essential for the TNC in order to perform numerous functions involving multi-axis machining.




Tool radius R

You can enter the tool radius R directly.

Delta values for lengths and radii

Delta values are offsets in the length and radius of a tool. A positive delta value describes a tool oversize (**DL**, **DR**, **DR2**>0). If you are programming the machining data with an allowance, enter the oversize value in the **TOOL CALL** block of the part program. A negative delta value describes a tool undersize (**DL**, **DR**, **DR2**<0). An undersize is entered in the tool table for wear. Delta values are usually entered as numerical values. In a **TOOL CALL** block, you can also assign the values to Q parameters. Input range: You can enter a delta value with up to \pm 99.999 mm.




8.2 Entering tool data in the table

Abbr	Operation	Diglog
Т	Number by which the tool is called in the program	-
NAME	Name by which the tool is called in the program (no more than 12 characters, all capitals, no spaces)	Tool name?
L	Compensation value for tool length L	Tool length?
R	Compensation value for the tool radius R	Tool radius R?
R2	Tool radius R2 for toroid cutters (only for 3-D radius compensation or graphical representation of a machining operation with spherical or toroid cutters)	Tool radius R2?
DL	Delta value for tool length L	Tool length oversize?
DR	Delta value for tool radius R	Tool radius oversize?
DR2	Delta value for tool radius R2	Tool radius oversize R2?
LCUTS	Tooth length of the tool for Cycle 22	Tooth length in the tool axis?
ANGLE	Maximum plunge angle of the tool for reciprocating plunge-cut in Cycles 22 and 208	Maximum plunge angle?
TL	Set tool lock (TL: for Tool Locked)	Tool locked? Yes = ENT / No = NO ENT
RT	Number of a replacement tool, if available (RT: for Replacement Tool; see also TIME2)	Replacement tool?
TIME1	Maximum tool life in minutes. This function can vary depending on the individual machine tool. Your machine manual provides more information on TIME1.	Maximum tool age?
PLC	Information on this tool that is to be sent to the PLC	PLC status?

8.3 Editing tool tables

The tool table that is active during execution of the part program is designated as TOOL.T. You can only edit TOOL.T in one of the machine operating modes. Other tool tables that are to be archived or used for test runs are given different file names with the extension .T.



Step	Operation	
1	Select the Manual Operation mode	
2	TABLE Press the TOOL TABLE soft key to select the tool table.	
3	Set the EDIT soft key to ON	
4	Select the line in the tool table	
5	If needed, select the column.	
6	When you have opened the tool table, you can edit the tool data by moving the cursor to the desired position in the table with the arrow keys or the soft keys. You can overwrite the stored values, or enter new values at any position. The available editing functions are illustrated in the table below.	

Soft key	Editing function in table mode
BEGIN	Select beginning of table
END	Select end of table
PAGE	Select previous page in table
PAGE 	Select next page in table
FIND TOOL NAME	Look for the tool name in the table
FORM	Show tool information in columns or show all information on one tool on one screen page
BEGIN LINE	Move to beginning of line
END LINE	Move to end of line
COPY	Copy highlighted field
PASTE FIELD	Insert copied field
APPEND N LINES	Add the entered number of lines (tools) at the end of the table.
INSERT	Insert a line for the indexed tool number after the active line. The function is only active if you are permitted to store multiple compensation data for a tool (MP7262 not equal to 0). The TNC inserts a copy of the tool data after the last available index and increases the index by 1. Application: e.g. stepped drill with more than one length compensation value.
DELETE	Delete current line (tool).
POCKET # DISPLAY HIDE	Display / Do not display pocket numbers.
TOOLS DISPLAY HIDE	Display all tools / only those tools that are stored in the pocket table.

8.4 Pocket table for tool changer

For automatic tool changing you need the pocket table TOOL_P.TCH. The TNC can manage several pocket tables with any file names. To activate a specific pocket table for program run you must select it in the file management of a Program Run mode of operation (status M).

In order to be able to manage various magazines in a tool-pocket table (indexing the pocket number), Machine Parameters 7261.0 to 7261.3 must not be equal to 0.

Step	Operation	
1	TOOL TABLE	Press the TOOL TABLE soft key to select the tool table.
2	POCKET TABLE	Press the POCKET TABLE soft key to select the pocket table.
3	EDIT OFF ON	Set the EDIT soft key to ON. On your machine this might not be necessary or even possible. Refer to your machine manual.

8.5 Entering Pocket data in the table

Abbr	Operation	Diglog
Р	Pocket number of the tool in the tool magazine	
Т	Tool number	Tool number?
ST	Special tool with a large radius requiring several pockets in the tool magazine. If your special tool takes up pockets in front of and behind its actual pocket, these additional pockets need to be locked in column L (status L).	Special tool?
F	Fixed tool number. The tool is always returned to the same pocket in the tool magazine	Fixed pocket? Yes = ENT / No = NO ENT
L	Locked pocket (see also column ST)	Pocket locked Yes = ENT / No = NO ENT
PLC	Information on this tool pocket that is to be sent to the PLC	PLC status?
TNAME	Display of the tool name from TOOL.T	

Soft key	Editing function in table mode
BEGIN	Select beginning of table
END	Select end of table
PAGE	Select previous page in table
PAGE	Select next page in table
RESET POCKET TABLE	Reset pocket table
RESET COLUMN T	Reset tool number column T
NEXT LINE	Go to beginning of next line
RESET COLUMN	Reset column to original state. Only applies to the columns RSV, LOCKED_ABOVE, LOCKED_BELOW, LOCKED_LEFT and LOCKED_RIGHT

9. ATC Operation

9.1 Manual ATC Operation

Step	Operation
1	Select the Manual Operation mode
2	MOD Select the MOD Key
3	HEL? Select the Softkey
	Select the command line #301 ~ #313 NINCLOS Programming and editing Programming and editing Programming and editing
4	Ill attention III only for supervisor X. V. Z can be soued by X. V. Z can be soued by X. Y. Y. Y. Y. Z. Z. key or handwheel service tool changer (Coosan Infracore DMH type) ### Tool to toolchange position (Spindle orientation) ####################################
	0% S-ACT 0% SLORD LIMIT 18:12
5	Confirm your entry with the machine START button.

Number	Function
#301	S to tool change position
#302	Z to tool change position
#303	Tool pocket Down
#304	Tool pocket up
#305	Tool changer one cycle
#306	Tool changer setup CW
#307	Tool changer setup CCW
#308	Magazine turn CW
#309	Magazine turn CCW
#310	Magazine reference
#311	Delete spindle status
#312	Tool unclamping
#313	Tool calmping

10. Manual Data Input (MDI)

The Positioning with Manual Data Input mode of operation is particularly convenient for simple machining operations or prepositioning of the tool. It enables you to write a short program in HEIDENHAIN conversational programming or in ISO format, and execute it immediately. You can also call TNC cycles. The program is stored in the file \$MDI. In the Positioning with MDI operating mode, the additional status displays can also be activated.

Step	Operation	
1	Select operating mode: Positioning with MDI.	
2	Select the axis of the rotary table, enter the rotation angle you wrote down previously and set the feed rate. For example: L C+2.561 F50	
3	Conclude entry.	
4	Press the machine START button: The rotation of the table corrects the misalignment.	

11. Program Run

Program Run, Full Sequence

Start the part program with the machine START button.


Program Run, Single Block

Start each block of the part program individually with the machine START button.

11.1 Program start


Step	Operation		
1	e or		
	Select operating mode: Program Run, Single Block or Program Run, Full Sequence		
2	PGM MGT button		
3	Call the file manager with the PGM MGT key and select the file		
4	Go to the program beginning: Select line 0 with the GOTO key and confirm your entry with the ENT key.		
5	Press the machine START button:		

11.2 Mid-program startup (block scan)



11.3 Automatic Program Start

In a Program Run operating mode, you can use the AUTOSTART soft key (see figure at upper right) to define a specific time at which the program that is currently active in this operating mode is to be started:



11.4 Optional Block Skip

In a test run or program run, the TNC can skip over blocks that begin with a slash "/":

Step	Operation		
1	To run or test the program without the blocks preceded by a slash set the soft key to ON.		
2	ON	To run or test the program with the blocks preceded y a slash, set the soft key to OFF.	
0	Erasing the "/" character		
3	X	In the Programming and Editing mode you select the block in which the character is to be erased.	

11.5 Optional Program-Run Interruption

Step	Operation		
1	ON OFF	Do not interrupt Program Run or Test Run at blocks containing M1: Set soft key to OFF.	
2	ON OFF	Interrupt Program Run or Test Run at blocks containing M1: Set soft key to ON.	

12. File Management

NOTICE

Please refer to NC handling manual for detail information.


12.1 Fundamentals

Files in the TNC	Туре	Description
Programs	.Н	HEIDENHAIN format
	.1	DIN/ISO format
	.HU	Structured unit program
smarT.NC files	.HC	Contour descriptions
	.HP	Point tables for machining positions
	.T	Tools
	.TCH	Tool changers
	.P	Pallets
	.D	Datums
Tables	.PNT	Points
	.PR	Presets
	.CDT	Cutting data
	.TAB	Cutting materials, workpiece materials
	.DEP	Dependent data (such as structure items)
Texts	.A	ASCII files
Texts	.CHM	Help files
Drawing data	.DXF	
	.CFT	Fixture templates
Other files	.CFX	Parameterized fixtures
	.DEP	Dependent data (such as structure items)

12.2 Calling the file manager



Press the PGM MGT key: The TNC displays the file management window (see figure for default setting. If the TNC displays a different screen layout, press the WINDOW soft key.)



Display	Meaning	
File name	Name with max. 25 characters	
Туре	File type	
Size	File size in bytes	
Changed	Date and time that the file was last changed. The date format can be set.	
Status	File properties: E: Program is selected in the Programming and Editing mode of operation. S: Program is selected in the Test Run mode of operation. M: Program is selected in a Program Run mode of operation. P: File is protected against deletion and editing. +: Dependent files exist (structure file, tool usage file)	

12.3 Functions of the file manager

Soft key	Function
COPY ABC → XYZ	Copy (and convert) individual files
	Select target directory
SELECT TYPE	Display a specific file type
NEW FILE	Create new file
LAST FILES	Display the last 10 files that were selected
DELETE	Delete a file or directory
TAG	Tag a file
RENAME ABC = XYZ	Rename a file
PROTECT	Protect a file against editing and erasure
UNPROTECT	Cancel file protection
OPEN WITH	Open a smarT.NC program
NET	Manage network drives
COPY RBC → XYZ	Copy a directory
UPDATE TREE	Display all the directories of a particular drive

12.4 Selecting drives, directories and files

Step	Operation		
1	PGM MGT Select PGM MGT button		
	With the arrow keys or the soft keys, you can move the highlight to the desired position on the screen:		
	Moves the highlight from the left to the right window, and vice versa.		
2	Moves the highlight up and down within a window.		
	Moves the highlight one page up or down within a window.		
	Step 1: Select drive		
3	Move the highlight to the desired drive in the left window:		
4	To select a drive, press the SELECT soft key, or		
	ENT Press the ENT key.		
	Step 2: Select a directory		
5	Move the highlight to the desired directory in the left-hand window—the right-hand window automatically shows all files stored in the highlighted directory.		
6	SELECT Press the SELECT TYPE soft key.		
	Press the soft key for the desired file type, or		
7	Press the SHOW ALL soft key to display all files, or		
	4*.H Use wild card characters, e.g. to show all files of the file type .H that begin with 4.		
8	Move the highlight to the desired file in the right window		
9	Press the SELECT soft key, or		
	ENT Press the ENT key.		
10	The TNC opens the selected file in the operating mode from which you called the file manager.		

12.5 Creating a new part program

Step	Operation		
1	Select the Programming and Editing operating mode.		
2	PGM MGT Press the PGM MGT key to call the file manager.		
3	Select the directory in which you wish to store the new program:		
4	Select the NEW FILE softkey		
5	Enter the new program name and confirm your entry with the ENT key.		
6	To select the unit of measure, press the MM or INCH soft key. The TNC switches the screen layout and initiates the dialog for defining the BLK FORM (workpiece blank).		
7	WORKING SPINDLE AXIS X/Y/Z? Z Enter spindle axis, e.g. Z		
6	DEF BLK FORM: MIN CORNER? Enter in sequence the X, Y and Z coordinates of the MIN point and confirm each of your entries with the ENT key.		
7	DEF BLK FORM: MAX CORNER? Enter in sequence the X, Y and Z coordinates of the MAX point and confirm each of your entries with the ENT key.		
8	Programming and editing Def BLK FORM: max-corner? Ø BESIN PGH BLK HM 1 BLK FORM 0.1 Z X+0 Y+0 Z-40 2 BLK FORM 0.2 X+100 Y+100 Z+0 3 END PGM BLK HM		

12.6 Programming tool movements in conversational format

Step	Operation		
1	Dialog initiation		
	COORDINATES?		
2	X 10 Enter the target coordinate for the X axis.		
3	Enter the target coordinate for the Y axis, and go to the next question with ENT		
	RADIUS COMP. RL/RR/NO COMP. ?		
4	Enter "No radius compensation" and go to the next question with ENT.		
_	FEED RATE F=? / F MAX = ENT		
5	Enter a feed rate of 100 mm/min for this path contour; go to the next question with ENT.		
	MISCELLANEOUS FUNCTION M?		
6	Enter the miscellaneous function M3 "spindle ON." Pressing the ENT key terminates this dialog.		
7	3 L X+10 Y+5 R0 F100 M3		
The program-block window displays the following line:			
8	Programing and editing miscellaneous function HT 1 BLK FORM 0.1 2 x-0 Y+0 2-40 2 BLK FORM 0.2 x+100 Y+100 2+0 3 TOOL CALL 1 2 S5000 4 L Z+100 RB FHRX 5 L X-20 Y+30 RB FHRX 6 END PGH NEU HH 1 H94 H103 H118 H120 H124 H128 H138		

Key	Function	
NO ENT	Ignore the dialog question	
END	End the dialog immediately	
DEL	Abort the dialog and erase the block	